

2019+ CRF110F Air Filter Cage Install Instructions

1. Remove the four 8mm bolts on air box lid
2. Remove Air filter
3. Bend back lock tabs to expose the two #2 Philips bolts
4. Remove #2 Phillips bolts
5. Remove the Stock cage and Screen assembly
6. Install the RAD Air Filter cage Seating the round end with the intake boot.
7. Reinstall the two #2 Philips screws, you do not the locking tabs
Note: double check the mating of the cage and the intake boot again you may need to run a flat blade screwdriver around the inner edge of the boot to allow it to seat into the groove of the cage.
8. Install air filter
9. Reinstall the air box lid and four 8mm screws