

2019+ CRF110F INTAKE TUBE INSTRUCTIONS

1. Remove seat, two 8mm bolts
2. Remove side plastics, three 8mm bolts and 2 push pins
3. Remove gas tank, three 12mm bolts, electrical connector and fuel line

NOTE: Fuel line is a quick disconnect that you simply push the tab in and pull off

4. Remove airbox cover four 8mm bolts
5. Remove air filter and cage assembly, two #2 Philips screws
6. Loosen clamp at throttle body and pull off stock intake tube

NOTE: To fully remove tube you may need to use a heat gun to warmup the glue holding the tube into the airbox

7. Take the large end of the RAD intake tube and fold it in on itself, then insert it into the airbox hole, make sure the tube seats into the groove and sits flush against the airbox
8. From inside the airbox make sure the tube is round and not folded in on itself
9. Install air filter cage, if using the rad cage make sure the tube seats into groove on the back of the cage
10. Install air filter and airbox cover
11. Install stock clamp onto throttle body side of intake tube, push tube onto the throttle body, and tighten clamp
12. Install gas tank
13. install side plastics and seat